
CS 137: File Systems

Persistent Solid-State Storage

Technology Change is Coming

- Disks are cheaper than any solid-state memory
- Likely to be true for many years
- But SSDs are now cheap enough for some purposes



ROM

- ► ROM (Read-Only Memory) chips were programmed in the factory
 - Array of transistors
 - Trivial to leave out a wire to make one "defective"
 - Result was array of ones and zeros
- Most of chip predesigned; only one mask layer changed
- Still fairly expensive for that mask
- Ultra-low cost in large volumes

PROM

- ▶ PROM (Programmable ROM) is field-programmable
 - Array of fuses (literally!)
 - Blow a fuse to generate a zero
 - Special high-voltage to select fuse
- Much more expensive per-chip than ROM
- But low startup cost made cheaper in low volumes
- One-time use meant lots of chips thrown away

EPROM


- EPROM (Erasable PROM) used floating-gate technology
 - Direct predecessor to flash
 - Electrons in floating gate (see later slide) store data
 - UV light used to drive out electrons and erase
- 15 minutes to erase
- Reusability dropped cost



EEPROM

- ▶ EEPROM (Electrically Erasable PROM) used thinner oxide layer
- ► Introduced ca. 1983
- High voltage could erase without UV


The Flash Cell



- Source line provides voltage, bit line senses
- Current flows between "N" regions, through "P"
- Voltage on control gate restricts current flow in "P"
- Charge on floating gate "screens" control gate
 - Allows sensing charge


Programming NOR Flash

Programming Via Hot Electron Injection



- Default state is 1 (current can flow)
- Apply high voltage to control gate
- Run current through channel
- "Hot" electrons jump through insulation to floating gate

Erasing NOR Flash



- Apply reverse voltage to control gate
- Disconnect source
- Electrons will now tunnel off floating gate


Wear-Out

- Some electrons get stuck in oxide during programming
- Add to electric field
- Eventually becomes impossible to erase effectively

Multilevel Cells (MLC)


- Classic flash stores charge or not: zero or one
- Possible to store different charge quantities
 - Sense varying current levels
 - Can translate back into multiple bits
 - Current limit is eight levels, three bits
- Obvious density improvement
- Slower to read and write
- Poorer reliability
- Chips often combine single-level cells (SLC) for speed with MLC for density.

NOR Flash



- All bit lines tied together
- Readout voltage placed on exactly one word line
- If "0" stored, nobody conducts
- If "1" stored, bit line is shorted to ground
 - Works like NOR of word lines

NAND Flash



- Extra-high voltage placed on all but one word line
 - All will conduct
- Remaining line gets "just barely" voltage
 - If programmed, will conduct
- Lower number of bit & ground lines means better density
- Programming via tunnel injection, erase via tunnel release

Comparison of NOR and NAND

NOR flash:

- Lower density
- Usually wired for true random read access
- Wired to allow writing of individual cells
- Erase in blocks of 64-256 KB

NAND flash:

- Cells take about 60% of NOR space
- More space saved by block-read wiring
- Writing ("programming") is in page-sized chunks of 0.5-4 KB
- Erase in blocks of 16-512 kB
- Extra bits to provide ECC and per-page metadata
- OK to have bad blocks

Structure of a NAND Chip

Samsung K9F8G08U0M (1G×8)

- Each page is 4K bytes + 128 extra
- One block is 64 pages
- Entire device is 8448 Mbits
- 5-cycle access: CAS1, CAS2, RAS1, RAS2, RAS3
 - Eight address bits per cycle
 - CAS is 13 bits + 3 for future
 - RAS is 18 + 6 for future
- RAS loads 4K+128 into Page Register

Chip Commands

Samsung K9F8G08U0M accepts 16-bit commands, such as:

- Reset
- Read
- Block Erase
- Page Program
- Read Status
- Read for Copy Back
- Copy-Back Program

"Two-plane" commands available for overlapped speedup

Random programming prohibited—but can go back and change metadata

Chip Timing

For Samsung K9F8G08U0M:

- ▶ Block erase: 2ms (probably not accurate to μ s level)
- Program: 700μs
- Read page to buffer: 25μs
- Read bytes: 25ns per byte

Bottom line:

- ightharpoonup 25 μ s + 4096 imes .025 = 25 + 102.4 = 127.4 μ s to read a page
- ► $102.4\mu s + 700 = 802.4\mu s$ to write if already erased
 - ▶ Otherwise extra 31.25 μ s (amortized) to erase

Chip Timing

For Samsung K9F8G08U0M:

- ▶ Block erase: 2ms (probably not accurate to μ s level)
- Program: 700μs
- Read page to buffer: 25μs
- Read bytes: 25ns per byte

Bottom line:

- ightharpoonup 25 μ s + 4096 imes .025 = 25 + 102.4 = 127.4 μ s to read a page
- ▶ 102.4μ s + $700 = 802.4\mu$ s to write if already erased
 - Otherwise extra 31.25 μ s (amortized) to erase

BUT 2ms latency if nothing currently erased.

Comparison to Disk Timing

For 3-TB Seagate Barracuda XT (3.5-inch):

- Average latency: 4.16 ms (7200 RPM)
- Average seek time: 8.5 ms (read), 9.5 ms (write)
- → 12.66 ms to read one random page
- Sustained transfer rate: 149 MB/s = 27.5μ s per 4K bytes

Bottom line: 12.66 ms to read one random page (ouch!), but sequential reads are 5X faster than flash chip, and sequential writes are 30X faster

The Technology

Comparison to Disk Timing

For 3-TB Seagate Barracuda XT (3.5-inch):

- Average latency: 4.16 ms (7200 RPM)
- Average seek time: 8.5 ms (read), 9.5 ms (write)
- 12.66 ms to read one random page
- Sustained transfer rate: 149 MB/s = 27.5μ s per 4K bytes

Bottom line: 12.66 ms to read one random page (ouch!), but sequential reads are 5X faster than flash chip, and sequential writes are 30X faster

But can wire flash chips in parallel to increase bandwidth

Issues in Using Flash for Storage

- Pre-erasing blocks
- Wear leveling
- Clustering blocks for group writing
- Efficient updates
- ECC and bad-block mapping

Issues in Simulating a Disk

- Can't tell what blocks are live
- Expected to allow random updates
- Some blocks (e.g., FAT, inode table) much hotter than others

General Solution: Flash Translation Layer

- All flash "drives" have embedded μ processor (usually 8051 series)
- Give block-numbered interface to outside world
- Hold back some memory (e.g., 5G drive pretends to be 4G)
- Map externally visible blocks to internal physical ones
- Use metadata to track what's live, bad, etc.

Problems in FTLs

- Wear leveling (what if most blocks are read-only?)
 - Solution: must sometimes move RO data
- File system wants to rewrite randomly
 - Solution: group newly written blocks together regardless of logical address
 - Called "Log-Structured File System" (LFS)
- Unused block might or might not be live
 - Solution: only reclaim block when overwritten
 - Solution: know that it's FAT and reverse-engineer data as it's written

A Better Way

- Pretending to be a disk is just plain dumb
- When disks came out, we didn't make them look like punched cards
 - Well...mostly
- If filesystem designed for flash, don't need FTL
 - Problem: need entirely new interface
 - So far, manufacturers reluctant (chicken and egg)
- Some filesystems designed just for flash: YAFFS, JFFS2, TrueFFS, etc.
- Can expect further development

The Bad News

- Feature-size limit is around 20 nm
- We're hitting that just about now!
- Some density improvement from MLC, maybe 3-D stacking
- This might kill flash as a disk replacement

Other options

Flash isn't the only choice:

- Phase-change memory (PRAM or PCRAM)
- Magnetic RAM (MRAM)
- ▶ ???

New technologies offer

- Read/write times slightly slower than DRAM
- No wear-out
- Longer storage life without refresh
- Byte addressability
 - What happens when filesystems are just like memory?